





8933

TABLET HOLDER WALL




DE Gebrauchsanleitung
GB Instruction Manual
FR Notice d'emploi
NL Instructies
ES Manual de instrucciones
IT Istruzioni d'uso
SE Bruksanvisning
PL Instrukcją obsługi
RU Руководство по эксплуатации













360°






3 | TABLET HOLDER WALL









4 | TABLET HOLDER WALL






















DURABLE

DURABLE · Hunke & Jochheim GmbH & Co. KG

Westfalenstraße 77-79 · 58636 Iserlohn

P.O. Box 1753 · 58634 Iserlohn · Germany

Phone ++49-2371-662-0 · Fax ++49-2371-662-221

durable@durable.de · www.durable.eu